


Pre-Installed Servers

Untangle offers servers for your convenience that come with the Untangle Gateway Platform pre-installed. Just plug it in, activate the services you want, and you're good to go. XD Servers are recommended for up to 250 users, features whisper-quiet operation, and comes with a one-year limited warranty.

| | | XD | XD+ |
|---|---------------------------|--|--------------------------------------|
| XD Servers  | Processor | Intel Pentium D, dual core 2.66GHz | Intel Pentium D, dual core 2.8GHz |
| | Memory | 1 GB | 2 GB |
| | Storage | 80 GB | |
| | Throughput | 100Mbps | |
| | Interfaces | 3 auto-sensing 10/100 Ethernet RJ45 ports | |
| | Power | 100-127 / 200-240 VAC | |
| | Additional Rear IO | <ul style="list-style-type: none"> • 4 USB 2.0 ports • PS/2 keyboard & mouse ports • VGA video port | |
| | Chassis | Mini-tower | |
| | Dimensions | 13.0" H x 3.7" W x 15.2" D 33.0cm H x 9.4cm W x 38.6cm D | |

XD servers are UL and FCC compliant and come with a one-year limited warranty

OPTIONS

XD Rackmount Kit - Mount your XD server in a standard 19" rack with this sturdy 2.5U high, black powder coat, welded steel tray.
Dimensions 3.8" (9.7cm) H x 19" (48.3cm) W x 14.9 (37.8cm) D



24-hour Priority Replacement option - back-up your Untangle Server's entire configuration (except reports) to Untangle's datacenter every night. If your server should ever fail, Untangle will have a replacement delivered to you with the exact same configuration, ready to be plugged in, within 24 hours.

You can also install Untangle on your own dedicated server.

The minimum system requirements are:

- Processor: Intel compatible, Min 1.0 Ghz, (Recommend 2.0+ Ghz)
- Memory: Min 512 meg (Recommend 1 Gig)
- Storage: Min 20 Gig (Recommend 40+ Gig)
- Interfaces: Min 2 10/100 Ethernet RJ45 ports (3+ for DMZ and other network topologies)
- CD-ROM drive to boot Untangle CD

Untangle

2800 Campus Drive, Suite 100
San Mateo, CA 94403
Tel: 866-233-2296 / 650-425-3300
www.untangle.com